

A recent variation on these systems includes membranes that have an integral adhesive built onto the back of the membrane – these are referred to as self-adhered or peel-and-stick systems. The elimination of liquid-adhesive application can provide additional installation savings.

Care must be used in selecting adhesive systems when InsulFoam products are being used. The insulation can be damaged when exposed to petroleum- or solvent-based adhesives or primers. When these materials are used in the system, InsulFoam shall receive a cover board of wood fiber, oriented strand board, gypsum or DensDeck®. Water-based and urethane adhesives have been found to work extremely well when placed directly over InsulFoam. However, fire ratings for these systems are somewhat limited at this time.

Ballasted Ballasted single ply systems typically use aggregate (round river-washed rocks), 0.75 to 1.5 inches in diameter, installed between 10 to 12 pounds per square foot. The ballast is applied directly over loosely laid membrane and insulation. While adding ballast to a loosely laid roof is most commonly associated with EPDM, other membranes can also take advantage of this fastening method. The designer must consider both the additional weight of the ballast as well as the probability of the structures exposure to high winds. In high-wind areas, ballast can be lifted from the roof and cause damage to surrounding buildings or individuals. It should be noted that manufacturers of PVC membranes often do not permit the use of ballasted systems with their membranes. As an alternate to aggregate, concrete pavers, which can withstand freeze-thaw cycles, can be applied over a non-woven fleece pad to anchor the membrane. These systems are generally accepted as having the lowest installed cost per square foot, followed by mechanically fastened and fully adhered (excluding self-adhered) systems.

InsulFoam is an ideal insulation for use in ballasted single ply membrane systems, and has been used successfully in these applications for over twenty years.

Multi-Ply Bituminous Membranes

Built-Up Roofing Systems Conventional bituminous built-up roofing (BUR) membranes have been used for over 100 years and represent a notable portion of today's roofing market. The membrane, in essence, is fabricated in place, (not in a factory), and consists of layers of waterproofing bitumen alternating with plies of reinforcing felts, and finished with a protective surfacing. The primary feature of BUR is the redundancy offered by multiple plies. Molten bitumen is typically applied at elevated temperatures. These systems can be used very effectively with InsulFoam; however, the use of cover boards and particular application techniques is required. Refer to the Insulation Specifications section for these application techniques.

InsulFoam products are not to be used with coal tar or coal-tar bitumen membranes.

Modified Bitumen Roofing Systems Polymer modification of bitumens has enhanced the properties of classic waterproofing materials used in built-up roofing. Traditional bitu-

men limitations, such as elongation, slippage in hot weather and flexibility in cold weather, have been improved with this innovation. In addition, because the properties of the bitumens were altered, new application techniques were developed. These enhanced bitumens are typically combined with reinforcements or carriers that complement the properties of modified bitumen blend. This results in sheet materials that have exceptional tensile strength, tear resistance and weatherability.

SBS (Styrene-Butadiene-Styrene) modified bitumens have excellent elongation and recovery properties, permitting repetitive exposure to the cyclic stresses caused by the expansion and contraction of underlying decks or substrates. The ability to accommodate these loads minimizes the potential of premature fatigue failure of the membrane. The rubberized blend also results in improved cold-weather performance.

APP (Atactic Polypropylene) modified bitumens use plastic modifiers to improve the properties of the asphalt. These materials are typically referred to as amorphous or atactic polypropylene. The products are ideal for heat weld or propane torch applications, as the blend on the back of the sheet acts as an integral hot-melt adhesive. Often, these products are reinforced with a polyester mat that creates excellent tensile strength and flexibility.

Direct exposure to the elements and ultraviolet light can result in premature aging of modified bitumen blends, and, for that reason, they are often produced with a protective coating of ceramic roofing granules.

Bituminous System Fastening Methods

Hot-Asphalt Attachment Built-up roofing (BUR) and SBS modified bitumen systems utilize hot asphalt to bond the membrane to the underlying substrate. The application temperature of the asphalt ranges from 335 °F to 450 °F. The use of a cover board is required over InsulFoam with the use of BUR or SBS membranes. The cover board can be attached using mechanical fasteners or hot asphalt application techniques. These techniques are described in the Insulation Specifications section of this manual.

Heat Welding Heat welding techniques differ depending on the membrane and application.

Heat welding of single ply membranes typically requires the use of a hot-air gun. This tool provides a stream of air that is hot enough to soften the membrane coating. Once the material has softened sufficiently, it will bond to another sheet of the same material, or, in some instances, specially coated metal flashing. This technique is used to seal field-seams, attach perimeter and penetration membrane flashing materials to the roof membrane and attach the membrane to perimeter metal.

Heat welding of modified bitumens can employ either a propane torch or hot-air gun. Both tools are used to soften the modified bitumen blend on the sheets to allow the material to bond to itself at field laps, roof insulation, other roof substrates and properly prepared perimeter metal.



ROOF MEMBRANES

The lap or bond to the roof substrate is complete once the membrane material has cooled.

Cold Adhesives Virtually any of the membranes described in this section can be built or secured to the roof substrate with adhesives. Many alternatives are available, and proper selection largely depends on the roofing components employed in the system.

Organic, solvent-based bonding cements have been used very effectively for many years. Although they work well with some membranes, most solvents in these adhesives can damage InsulFoam products. When these materials are used in systems employing InsulFoam, a cover board must be used to protect the insulation. Care must also be taken in applying the adhesive. Pouring large pools of adhesive on the cover board can penetrate the cover board and damage the insulation. **INSULFOAM WILL NOT ACCEPT, UNDER ANY CIRCUMSTANCES, ANY RESPONSIBILITY FOR DAMAGE TO INSULFOAM INSULATION OR SHEATHING PRODUCTS THAT IS CAUSED BY SOLVENTS FROM ADHESIVES.**

A number of low-solvent, urethane and water-based adhesives are also available for use with InsulFoam insulations. These systems may also require the use of a cover board. Membrane manufacturers typically provide their own brand or specify which adhesive materials are compatible with their membrane. Refer to membrane manufacturers' recommendations.

Self-Adhered Membranes Self-adhering membranes are manufactured with an integral adhesive film on the back of the sheet that is covered with a release paper or film. They are similar in design to adhesive bandage strips. These membranes are available from single ply membrane and modified bitumen manufacturers. The sheet is installed by removing the release paper while placing the membrane over the roof insulation or substrate. Depending on the Insulfoam product being used, a cover board may be required.

